

Kódy na nastavenie oscilátora modulu PLL pre meniče MTK TESA-S

Kód	frekv.
87654321	[MHz]
01111000	106
01111001	114
01111010	116
01111011	122
01111100	124
01111101	125.5
01111110	130
01111111	132
10000000	133.5
10000001	138
10000010	140
10000011	141.5
10000100	146
10000101	148
10000110	149.5
10000111	156
10001000	157.5
10001001	164
10001010	165.5
10001011	173.5
10001100	184
10001101	192
10001110	200
10001111	208
10010000	216
10010001	224
10010010	232
10010011	240
10010100	248
10010101	256
10010110	264
10010111	272
10011000	280
10011001	288
10011010	296
10011011	304
10011100	312
10011101	320
10011110	328
10011111	336
10100000	344
10100001	352
10100010	360
10100011	368
11001010	376
10100100	378
10100101	384
00000000	386
10100110	392
00000001	394
10100111	400

Kód	frekv.
87654321	[MHz]
00000010	402
10101000	408
00000011	410
00000100	412
10101001	416
00000101	418
00000110	420
00000111	421.5
10101010	424
00001000	426
00001001	428
00001010	429.5
10101011	432
00001011	434
00001100	436
00001101	437.5
10101100	440
00001110	442
00001111	444
00010000	445.5
10101101	448
00010001	450
00010010	452
00010011	453.5
10101110	456
00010100	458
00010101	460
00010110	461.5
10101111	464
00010111	466
00011000	468
00011001	469.5
10110000	472
00011010	474
00011011	476
00011100	477.5
10110001	480
00011101	482
00011110	484
00011111	485.5
10110010	488
00100000	490
00100001	492
00100010	493.5
10110011	496
00100011	498
00100100	500
00100101	501.5
10110100	504
00100110	506
00100111	508

Kód	frekv.
87654321	[MHz]
00101000	509.5
10101001	512
00101001	514
00101010	516
00101011	517.5
10101010	520
00101100	522
00101101	524
00101110	525.5
10101111	528
00101111	530
00110000	532
00110001	533.5
10111000	536
00110010	538
00110011	540
00110100	541.5
10111001	544
00110101	546
00110110	548
00110111	549.5
10111010	552
00111000	554
00111001	556
00111010	557.5
10111011	560
00111011	562
00111100	564
00111101	565.5
10111100	568
00111110	570
00111111	572
01000000	573.5
10111101	576
01000001	578
01000010	580
01000011	581.5
10111110	584
01000100	586
01000101	588
01000110	589.5
10111111	592
01000111	594
01001000	596
01001001	597.5
11000000	600
01001010	602
01001011	604
01001100	605.5
11000001	608
01001101	610

Kód	frekv.
87654321	[MHz]
01001110	612
01001111	613.5
11000010	616
01010000	618
01010001	620
01010010	621.5
11000011	624
01010011	626
01010100	628
01010101	629.5
11000100	632
01010110	634
01010111	636
01011000	637.5
11000101	640
01011001	642
01011010	644
01011011	645.5
11000110	648
01011100	650
01011101	652
01011110	653.5
11000111	656
01011111	658
01100000	660
01100001	661.5
11001000	664
01100010	666
01100011	668
01100100	669.5
11001001	672
01100101	674
01100110	676
01100111	677.5
01101000	682
01101001	684
01101010	685.5
01101011	690
01101100	692
01101101	693.5
01101110	698
01101111	700
01110000	701.5
01110001	706
01110010	708
01110011	709.5
01110100	716
01110101	717.5
01110110	724
01110111	725.5

6/5423030